

BRICON Club system

Belgian Racing pigeons Information and registration system

Manual for basketing with BRICON in the club

CL-BSC/TW-ENG/08



BRICON nv

Hoge Heerweg, 49 9100 Sint-Niklaas Belgium
Tel: +32 (0)3/ 777 39 74 Fax: +32 (0)3/ 778 07 35
website: www.bricon.be / e-mail: bricon@bricon.be

Contacts: Ludo Wille: GSM +32 (0)475/ 25 30 21

The BRICON CLUB SYSTEM.

Manual: contents

1. Introduction	3
1.1. Electronic clocking systems, the basic principles	3
1.2. What is RFID?	3
1.3. Which are the advantages of RFID?	3
1.4. RFID and electronic clocking	3
2. Parts and installation of the BRICON CLUBSYSTEM	5
2.1. The Bricon basketing antenna	5
2.2. The Bricon mother clock	5
2.3. The printer	5
2.4. The PC	6
3. Installation of the PC software	7
3.1. Installation	7
3.2. Making a short cut to the desktop	9
3.3. Preparing the BRICON CLUBSYSTEM	11
3.4. The main menu of Upload 95	14
3.4.1. Club data	14
3.4.2. Races/Badges	15
3.4.3. More clubs	16
3.4.4. Fancier data	17
3.4.4.1. Connecting the rings through the computer	18
3.4.4.2. Connecting the rings through the EC	22
3.4.5. Set up	23
3.4.6. Close	23
4. Most important functions of the EC	24
4.1. Set up	24
4.1.1. Set number of print-outs	24
4.1.2. Set number of lines of the print-out	25
4.1.3. Set auto-print	26
4.1.4. Set the clock type	27
4.1.5. Set the basketnumber	28
4.1.6. Set speed calculation	29
4.1.7. Set your language	30
4.1.8. Make a PC connection	31
5. Basketing	32
5.1. Basketing, synchronise with the atomic clock	32
5.2. Basketing, synchronise manually	33
5.3. Basketing, synchronise with master clock	36
5.4. The basketing list in detail	41
6. Reading	42
6.1. Reading, synchronise with the atomic clock	42
6.2. Reading, synchronise manually	43
6.3. Reading, synchronise with master clock	45
6.4. The clocking list in detail	49
7. Trouble shooting	50
7.1. Power fails when basketing/adding a pigeon to a flight	50
7.2. Pigeon already basketed	50
7.3. Removing data from the EC	51
7.4. Pigeon not listed! Emergency entry while basketing	52
7.5. Wrong ring number while basketing	53
7.6. What is left in the fancier's EC	54
7.7. The ring is not being read	54
7.8. New print of the basketing list	55
7.9. Accidentally pressed <C> before the last pigeon was fully basketed	56
7.10. Printing the logbook - Overview of the last series of clockings	56
7.10.1. Logbook in detail	57
7.11. Printing basketing list from the EC.	58

The BRICON CLUB SYSTEM.

Elektronic clocking in the club

1. Introduction

1.1. Electronic clocking systems, the basic principles.

The basic principle of an electronic clocking device is the identification of a pigeon from a distance or identification without direct contact. RFID (Radio Frequency Identification) is one of the techniques used for this purpose. This technology has become very popular since the eighties and is already being frequently used. Electronic clocking systems for pigeons use RFID.

1.2. What is RFID?

RFID systems consist of three elements: an antenna, a decoder and a transponder. The antenna emits radio signals which activate the transponder. The data can be read in the transponder and can be written on. The antenna is the link between the transponder and the decoder. The contact between the antenna and the transponder is wireless and consists of radio waves. The transponder holds the identification data, the decoder interprets these data and controls the antenna.

A transponder consists of the following components:

- a spool used as an antenna,
- a chip (IC) which has a radio transmitter / receiver and a computer with a memory.
- A transponder can only function if it is supplied by power. Depending on the power source we talk about:
 - an active transponder or
 - a passive transponder

An active ID-transponder not only has a antenna spool and a chip, but also a battery supplying everything with power. This built-in power source increase the performances of the transponder, enabling it to be read and/or be written on on larger distances.

Passive ID-transponders have no internal power source, they get their power from the antenna. The advantage of these transponders is in their smaller sizes, their smaller production costs and their almost infinite life span. Since there is no power source their emitted signal is so weak they can only be read on limited distances.

1.3. What are the advantages of RFID?

The most important advantages of an RFID system can be reduced to the possibility to identify automatically without using pen and paper. It can be used in almost all circumstances.

- RFID is the obvious means in dusty, dirty, greasy, wet and even very aggressive places.
- RFID-transponders and readers have no moving parts, so the systems are very easy to maintain and have a very large life span.
- RFID can identify without physical contact.
- RFID is very swift, the connection can be made in a few hundredths of seconds.
- RFID still operates under very extreme circumstances.

1.4. RFID and electronic clocking.

An electronic clocking system actually is an RFID system composed of three elements:

- a transponder or chip ring
- a part in the club (universal basketing antenna, UBA), the BRICON CLUBSYSTEM,
- a part at the fancier's loft (loft antenna)
- and a part in which the data are stored.

The part in which the data are stored called in this document "terminal" or electronic clock (EC) for uniformity's sake.

The CLUB SYSTEM always remains in the club, the loft antenna is in the fancier's loft. The EC is the mobile part which has to be in the club when basketing or clocking.


By creating a standard we want to obtain a connection between the devices in the club and the terminal. The connection between the terminal and the loft antenna does not have to be

compatible since the fancier normally only uses the products of one manufacturer. In most countries a pigeon fancier is tied to one single club and cannot basket anywhere else. The fancier's individual freedom, regarding the choice of his electronic system, is quite limited. He can only choose the system his club uses, or he can opt for not clocking electronically. The persons responsible for the club decide what system should be used. In Belgium however, every fancier can basket in several (four, five or more) different clubs and enter several flights. Each fancier can choose from a large number of flights, that is probably the reason why the Belgian pigeon is so much wanted. Most races are flown in Belgium, and the selection is the hardest in Belgium.

Several clocking systems are put up for sale. In principle, these systems are not mutually compatible.

BRICON also developed a unique compatible system: the BRICON CLUBMASTER (this system is used in several countries, such as Belgium). This system enables you to basket without having to manipulate the fanciers' device. Each fancier is treated equally, the staff of the club only needs to know how their BRICON CLUBMASTER functions in order to be able to help each fancier with a homologated device. If you need more information about this system, you can contact your salesman.

2. Parts and installation of the BRICON CLUBSYSTEM.



1. Basketing antenna.
2. Printer.
3. PC.
4. BRICON Electronic clock (EC).
5. BRICON Mother clock..

2.1. The Bricon basketing antenna:

The antenna is used to read and write on the electronic (chip) rings. The antenna can simply get new software each time the KBDB homologates a new ring. The cable port of the antenna is connected to the entry "Antenna" on the "Unives box".

2.2. The Bricon mother clock:

The Bricon mother clock is a radio controlled clock which automatically synchronises itself with the "DCF" from Frankfurt. To be sure your mother clock gives the correct time, it has to be able to freely receive the signal from Frankfurt. Closed spaces in reinforced concrete, metal cupboards and the like disturb the signal of the emitter in Frankfurt. That is why you have to keep your mother clock on a spot where the radio signal can be easily received, preferably near a window. The cable of the mother clock can best be connected to the serial 9-pin connection (on the right at the back) on the antenna.

Important: half an hour before basketing or reading the mother clock has to be synchronised by pricking (with a toothpick or a needle) in the appropriate hole at the back.

2.3. The printer


A printer is necessary to print basketing and clocking lists. Each DOS compatible printer can be used, Windows printers are not fit and have trouble printing. You connect the basketing antenna to the printer with a printer cable. Normally the printer cable is a standard accessory of the printer.

2.4. The PC


Each PC functioning under DOS or Windows 95 / 98 can be used. The PC is connected to the CLUB SYSTEM by a serial RS-232 null modem cable. You can recognise the null modem cable by the female 9-pin plugs on both sides. A serial port of your PC connects you to the serial connection on the Bricon basketing antenna.

3. Installing the PC software.

3.1. Installation




Put the CD-rom in the CD-rom reader. Click "**Start**" at the bottom left of the Windows start-up screen. Click "**Execute**".




"Type "d (or the letter indicated by your CD-rom player): set up in the window "**Execute**" and click "**OK**".

The computer will now start installing the software.




After a while this window appears.

Click the "**Next**" button, this window appears:



Click the **"Next"** button, this window appears:




Click the **"Finish"** button.

The program has been installed.

3.2. Make a short cut to the desktop.

Then we make a short cut to the desktop. Start **Windows Explorer**. Click the "**Start**" button (at the down left of the Windows start-up screen). Then click "**Programs**" and "**Windows Explorer**" (see example).



We now started **Windows Explorer**.


Now click "**Program Files**", "**ADGSoft**", "**Upload95**" and "**Tables**" in the left side of the window.

Click "**Upload95.exe**" in the right field.


Click with your right mouse button and click "**Make a short cut**".

Click "**Short cut to Upload95.exe**".


Click "**Edit**" and "**Copy**" in the upper toolbar of **Windows Explorer** (see the following picture).



Close **Windows Explorer** (by clicking the cross at the top right) and click the right mouse button. The following window appears.



Click **"Paste"**. The start-up icon now appears on the desktop (see example).




By double-clicking the icon with the pigeon ("**Short cut to upload95.exe**"), the program is started.

3.3. Preparing the BRICON CLUBSYSTEM


When you start the program (by double-clicking "**Short cut tot upload95.exe**) you see the window "**Adjust Software**".



Choose before "**Without Master**" and click "**OK**". The window with settings appears. Here you can change the password.



Click "**Change Password**"



By old password you enter "**BAWIBO**". Enter the new password and confirm it. Press "**OK**". As from now you always have to use this password to use the software program.

Another icon in the settings menu is **Test Port**. With this you can test the communication between the BRICON CLUBSYSTEM and test the computer. Connect the computer with the cable to the BRICON CLUBSYSTEM, connect a Bricon clocking device (see 2. Parts and installation of a BRICON CLUBSYSTEM). Plug the power cable in the socket. After a few seconds the EC display shows:

```
- RACE (4)-
>1.Basketing
  2.Read
  3.Bets
  4.Designate
  5.Masterclock
```

On the display you have 3 possibilities. You can see more possibilities by scrolling with the vertical arrows through the menu.

Press <C>.

```
- Little 1000 -
> Clocking
  Menu
Time : 10:36:23
```

The main menu appears.
Press the downward vertical arrow.

```
- Little 1000 -
  Clocking
> Menu
Time : 10:36:51
```

"Menu" is selected.

Press <OK>.

```
- MENU (5)-
  1.Race
  2.Use data
  3.Options
  4.Set up
>5.PC interface
```

The MENU display with 5 possibilities appears.

Scroll with the vertical arrow until **"PC interface"** is selected.


```
Key please!
```

Keep the supplied badge on the antenna. The antenna is released to communicate with the fancier's device.


```
PC-comm. on hold
Press a key.
```

The BRICON SYSTEM can now communicate with the PC.

Now you can check on the PC if contact with the BRICON CLUBSYSTEM is possible. Select the right communication port. Choose Com 1. It should have a black dot. Click "**Check portal**".




If you cannot obtain a communication choose another com-port (Com 2, Com 3 or Com 4, it should have a black dot), click "**Check portal**" one more time until you see the following window.




Click 'OK'.

Now you have a communication between the PC and the BRICON CLUBSYSTEM. Click "**OK**".



You see the following window. Behind "**Info/Version**" you can find information regarding the program. By clicking "**Close**" you close the window.

3.4. The main menu of Upload95.




You have 6 possibilities:

- Club Data
- Races/Badges
- More clubs
- Fancier Data
- Set up
- Close

3.4.1. Club Data.

In the submenu **Club Data** you enter the data of the club which keeps the file of the pigeon lists. Click the button. In the following window you have to enter the right information per field. Do not forget to enter the identification number of the club (clubID). This ID number is the certified membership number of the club at the federation.

3.4.2. Races/Badges.




In the submenu **Races/Badges** a flight calendar can be made according to the needs of the club. Click **"Races/Badges"**.




In a following window the Races can be added. In the first column is the serial number. In the second column you can enter the flight (click in the column and enter the name). In the third column the flight can be activated (click the third column and activate the flight if necessary, there should be a little black dot to activate). The program now gives a flight ID itself to the flight you newly entered.

These flight data can be saved/written to disk by clicking the button **"To BRICON"**.


3.4.3. More clubs.



The submenu **More clubs** is developed for people who take care of several clubs. The different clubs are saved in this menu.



Each time the responsible person for a club makes a pigeon list, he sets this club as a standard by clicking the button "**Activate**". Each club - and each antenna - has its own identity, making it necessary to set a certain club as a standard.



The "**New**" button opens a window to add a new club. Here you add the required data of the new club, then click "**OK**".

Club Data

Name: Maatschappij Y

ClubID: 9292

Adress: Sporweg 1

City: 2000 Antwerpen

Country: België

Phone nr: 03 / 123 45 67

OK Cancel

The **"Change"** button opens a window to change the club data. Here you can change the club data, then click OK. See also **3.4.1. Club data**.

ClubID	Name	City
9191	Maatschappij K	Brussel
9292	Maatschappij Y	Antwerpen

Delete?

Delete current club?

Ja Nee

Activate New Change Delete Close

The **"Delete"** button opens a window to remove a club. Click **"Yes"** to remove.

To close the window, click **"Close"**.

3.4.4. Fancier data.

BRICON CLUB-Software for Windows 95

BRICON CLUB MASTER


Club Data Fancier Data

Races / Badges Setup

More Clubs Close


In this menu the fancier data are entered and the chip rings are coupled to the rings of the national federation.

Before data can be exchanged between a PC and an EC, you have to be sure that **all data of the flights and the training flights have been erased** in the EC of the fancier. Now click the button "**Fancier data**" in the PC program.




The following window is being started.

To enter fancier data, you click the button "**New**". A completely new card appears in a following window.



The fields can be filled in. The licence number is limited up to 8 characters.

3.4.4.1. Connecting the rings through the computer program.



Click the button "**New ring**". A new row is being created. If there is a preceding ring number the program will copy the first numbers itself.

Nr	FoRing	ELRing	Hen
1	BE-00-1234567		<input type="checkbox"/>
2	BE-00-12345		<input type="checkbox"/>

In the second field of the right part of the window you can type the ring number. For a ring with 7 characters the right way is this: **BE-00-4232589**. First the national code, then the year (the last two digits of the year) and then the ring number. Use the downward vertical arrow to enter a next ring number,. Then successively press **"enter"** and **"end"**, now you can enter the last characters.

Nr	FoRing	ELRing	Hen
1	BE-00-1234567	7A3B6C7E	<input checked="" type="checkbox"/>
2	BE-00-1234568		<input type="checkbox"/>
3	BE-00-1234569		<input type="checkbox"/>


The button **"Read ring"** allows the coupling of an electronic ring. Click the button.

Hold the chip ring above the basketing antenna. On the PC screen we can see that the coding of the read ring is written in the third field of the right part of the window.

Follow the instructions on the screen to stop the reading.


Nr	FoRing	ELRing	Hen
1	BE-00-1234567	7A3B6C0D	<input checked="" type="checkbox"/>
2	BE-00-1234568	7A5B9324	<input type="checkbox"/>
3	BE-00-1234569	7A3B6C2C	<input checked="" type="checkbox"/>
4	BE-00-1234572	7A3B6C7E	<input type="checkbox"/>
5	BE-00-1234573	7A5B9A47	<input checked="" type="checkbox"/>

In the fourth field of the right part of the window you can indicate whether the pigeon is a hen or a cock (click the box so it shows a little black dot).




To erase a ring: click the row which needs to be erased and click **"Delete ring"**.

When **"Multiple rings"** is being clicked, you can quickly generate a whole series of rings. It is preferable not to click **"Overwrite pigeonlist"**, otherwise the existing ring couples will be overwritten.



In the following window you can see that the complete series is being made.



With the button **"Read ring"** you can make a coupling between the electronic chip ring and the national foot ring again.

By clicking the button **"Write to EC"** all entered data will be transferred to the fancier EC, and the fancier is ready to participate in official races.

When the transfer was successful you get the following window:




Click "**OK**".

A fancier who owns a **Bricon clock (EC)** can connect the chip rings to the national foot ring himself at home. This connection is only temporary. These pigeons can still be erased or overwritten. If the fancier wants to participate in official flights, he has to have his pigeons blocked in his clock.

The big advantage is that the fancier can quietly enter his pigeon at home. The responsible person of the club has the advantage that he only needs to read, correct and write back the fancier's information.


For connecting the two rings of the pigeons in the EC we refer to the EC manual.




If the data are already in the EC you click the button "**Read from EC**", the data are being taken from the fancier's electronic clock (EC). Beware that the EC is connected to the CLUB SYSTEM. The computer asks if you want to continue, you click "**Yes**". The pigeon list which possible is in the EC (only for Bricon!) is also read and put in the PC program. The rings in the EC


are blocked from the moment you click "**Write to EC**". From now on the fancier can participate in official races

In a following window the program mentions that the data have been received successfully.





The procedure to make changes is the same procedure to enter a new fancier. Click "**Change**". The fields are already filled in. After a possible change the same procedure as for a new fancier is being followed.




To remove a fancier, you click the fancier and you click "**Delete**". When you click "**Yes**" in the following window, you remove all the data of this fancier.

To close the window click "**Close**".

3.4.4.2.. Connecting the chip rings to the official rings through the EC.


The chip rings can be connected to the rings of the national federation by the fancier himself in the EC. After this has happened training flights can be registered. In order to participate with the electronic clocking system in official races as well the EC has to be offered to a club which has a BRICON CLUB SYSTEM. This CLUB SYSTEM will read the connection from the EC in the computer and will continue coding. The chip rings have to be put on the **left foot** of the pigeon.

3.4.5. Set up.



The submenu **Set up** has already been treated in **3.3. Preparing the BRICON CLUBSYSTEM.**

3.4.6. Close.



To close the program click the last submenu: **Close.**

4. Most important functions of the EC

4.1. Set up.

4.1.1. Set number of printouts.

Function: In this menu the number of printouts can be set.

```
- Little 1000 -
> Clocking
  Menu
Time : 16:14:16
```

This is the start-up menu.

```
- Little 1000 -
  Clocking
> Menu
Time : 16:14:16
```

Press the “↓” arrow on the EC display EC till the item “**Menu**” is selected.

Press <OK>.

```
- MENU (5) -
 1.Race
 2.Use data
 3.Options
>4.Set up
 5.PC Interface
```

On the new display 5 submenus appear (the number between brackets indicates the number of submenus). We only see 3 submenu’s. By pressing the “↓” key or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected.

Select : “**Set up**”.

Press <OK>.

```
- SETUP (5) -
>1.Printer Setup
 2.Clock
 3.Antenna
 4.Basketing
 5.Other
```

Select “**Printer Set-up**”

Press <OK>.

```
-PRINTER SET -
>1.Copies
 2.Page lenght
 3.Auto print
```

Select “**Copies.**”

Press <OK>.

```
Number of pages
Current: 2
<C>Esc <OK>Chang
```

The standard value is 2.

Press <OK> to change the number of pages.

```
Number of pages
Give number:
```

Enter the new number of printouts (f.e. 1).

Press <OK>.

```
Number of pages
Current: 1
<C>Esc <OK>Chang
```

The new number is set.

4.1.2. Set number of lines of the printout.

Function: In this menu the number of lines for a printout can be set.

```
- Little 1000 -
> Clocking
  Menu
Time : 16:14:16
```

This is the start-up menu.

```
- Little 1000 -
  Clocking
> Menu
Time : 16:14:16
```

Press the “↓” arrow on the EC display till the item “**Menu**” is selected.
Press <OK>.

```
- MENU (5) -
1.Race
2.Use data
3.Options
>4.Set up
5.PC Interface
```

On the new display 5 submenus appear (the number between brackets indicates the number of submenus). We only see 3 submenu’s. By pressing the “↓” key or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected. Select : “**Set up**”.
Press <OK>.

```
- SETUP (5) -
>1.Printer Setup
2.Clock
3.Antenna
4.Basketing
5.Other
```

Select “**Printer Set up**”

Press <OK>.

```
-PRINTER SET -
1.Copies
>2.Page length
3.Auto print
```

Select “**Page length**”

Press <OK>.

```
Number of lines
Current: 60
<C>Esc <OK>Chang
```

The standard value is 60 (number of lines).

```
Number of lines
Give number:58
```

Enter the new number of lines (f.e. 58).

Press <OK>.

```
Number of pages
Current: 58
<C>Esc <OK>Chang
```

The new number is set.

4.1.3. Set Auto print.

Function: Printing a basketing list is time-consuming (depending on the printer). In this menu you can set up 'automatical printout' of the basketinglist after basketing.

```
- Little 1000 -
> Clocking
  Menu
Time : 16:14:16
```

This is the start-up menu.

```
- Little 1000 -
  Clocking
> Menu
Time : 16:14:16
```

Press the "↓" arrow on the EC display till the item "**Menu**" is selected.

Press <OK>.

```
- MENU (5) -
1.Race
2.Use data
3.Options
>4.Set up
5.PC Interface
```

On the new display 5 submenus appear (the number between brackets indicates the number of submenus). We only see 3 submenu's. By pressing the "↓" key or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected. Select : "**Set up**"

Press <OK>.

```
- SETUP (5) -
>1.Printer Setup
2.Clock
3.Antenna
4.Basketing
5.Other
```

Select "**Printer Set up**"

Press <OK>.

```
-PRINTER SET -
1.Copies
2.Page length
>3.Auto print
```

Select "**Auto. print.**"

Press <OK>.

```
Automatic
printing when
basketing?C.:YES
<C>Esc <OK>Chang
```

The default setting is 'YES', a basketinglist will be printed immediately after basketing.
Press <OK> to change the setting.

```
Automatic
printing when
basketing?
<C> NO <OK> Yes
```

When <C> is pressed no basketing list will be printed. The basketing list can be made afterwards and/or on another location (see **5.3. Print data from the EC**).

```
Automatic
printing when
basketing?C.:NO
<C>Esc <OK>Chang
```

The 'automatical printout' is switched off.

4.1.4. Set the clock type.

Function: This menu is used to select the clock type. There are three different methods of basketing: 1. Using the atomclock. 2. Using manual settings. 3. Using a masterclock.

```
- Little 1000 -
> Clocking
  Menu
Time : 16:14:16
```

This is the start-up menu.

```
- Little 1000 -
  Clocking
> Menu
Time : 16:14:16
```

Press the “↓” arrow on the EC display till the item “**Menu**” is selected.

Press <OK>.

```
- MENU (5) -
 1.Race
 2.Use data
 3.Options
>4.Set up
 5.PC Interface
```

On the new display 5 submenus appear (the number between brackets indicates the number of submenus). We only see 3 submenu's. By pressing the “↓” key or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected. Select : “**Set up**”.

Press<OK>.

```
- SETUP (5) -
 1.Printer Setup
>2.Clock
 3.Antenna
 4.Basketing
 5.Other
```

Select “**Clock**”

Press <OK>.

```
- CLOCK -
 1.Set Time
>2.Clock Type
```

Select “**Clock type**”.

Press <OK>.

Make a selection.

Press 1 for ‘Atomclock’ (used by most of the European countries, the clubsystem is using a *Motherclock* witch get synchronised automatically).

Press 2 for ‘Manual’ (each clock time needs to be set manual, for basketing and for read as well).

Press 3 for ‘Masterclock’ (the time of one clock is set manual and is used as reference time for all the other clocks).

```
1. Atomclock
2. Manual
3. Masterclock
Make your choice
```

4.1.5. Set the basket number.

Function: If in this menu the number of the basket can be set, the EC will ask for it during basketing when set.

```
- Little 1000 -
> Clocking
  Menu
Time : 16:14:16
```

This is the start-up menu.

```
- Little 1000 -
  Clocking
> Menu
Time : 16:14:16
```

Press the “↓” arrow on the EC display till the item “**Menu**” is selected.

Press <OK>.

```
- MENU (5) -
1.Race
2.Use data
3.Options
>4.Set up
5.PC Interface
```

On the new display 5 submenus appear (the number between brackets indicates the number of submenus). We only see 3 submenu’s. By pressing the “↓” key or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected.

Select : “**Set up**”.

Press<OK>.

```
- SETUP (5) -
1.Printer Setup
2.Clock
3.Antenna
>4.Basketing
5.Other
```

Select “**Basketing**”

Press <OK>.

```
- BASKETING -
>1.Basket Nb.
 2.Use M/min
 3.Basketing:FOS
```

Select “**Basket Nb**”

Press <OK>.

```
Enter basketnr.?
Current: NO
<C>Esc <OK>Chang
```

The default setting is ‘NO’, the basketingnumber will not be asked during basketing.

Press <OK> to change the setting.

```
Enter basketnr.?
<C> NO <OK> YES
```

Press <OK> to ask for the basket number during basketing.

```
Enter basketnr.?
Current: YES
<C>Esc <OK>Chang
```

The basket number will be asked during basketing.

4.1.6. Set speed calculation. (in M/min).

Function: A calculation of the speed (in M/min) can be made in case the correct distance is known.

```
- Little 1000 -
> Clocking
  Menu
Time : 16:14:16
```

This is the start-up menu.

```
- Little 1000 -
  Clocking
> Menu
Time : 16:14:16
```

Press the “↓” arrow on the EC display till the item “**Menu**” is selected.

Press <OK>.

```
- MENU (5) -
 1.Race
 2.Use data
 3.Options
>4.Set up
 5.PC Interface
```

On the new display 5 submenus appear (the number between brackets indicates the number of submenus). We only see 3 submenu’s. By pressing the “↓” key or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected.

Select : “**Set up**”.

Press<OK>.

```
- SETUP (5) -
 1.Printer Setup
 2.Clock
 3.Antenna
>4.Basketing
 5.Other
```

Select “**Basketing**”

Press <OK>.

```
- BASKETING -
 1.Basket Nb.
>2.Use M/min
 3.Basketing:FOS
```

Select “**Use M/min.**”

Press <OK>.

```
Use M/min.?
Current: YES
<C>Esc <OK>Chang
```

The default setting is ‘YES’, the speed will be calculated by read and printed on the ‘Race clocking list’. The EC will ask for the correct distance between the fancier’s loft and the place wher the pigeons are freed.

Press <OK> to change the setting.

```
Use M/min.?
<C> NO <OK> YES
```

Press <OK> to let the EC calculate the speed.

Press <C> if you don’t want to use this menu.

```
Use M/min.?
Current: NO
<C>Esc <OK>Chang
```

The speed will not be calculated if <C> was pressed in the previous display.

Press ‘Esc’ to stop.

4.1.7. Set your language.

Function: In this menu the language can be set.

```
- Little 1000 -
> Clocking
  Menu
Time : 16:14:16
```

This is the start-up menu.

```
- Little 1000 -
  Clocking
> Menu
Time : 16:14:16
```

Press the “↓” arrow on the EC display till the item “**Menu**” is selected.

Press <OK>.

```
- MENU (5) -
 1.Race
 2.Use data
 3.Options
>4.Set up
 5.PC Interface
```

On the new display 5 submenus appear (the number between brackets indicates the number of submenus). We only see 3 submenu’s. By pressing the “↓” key or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected.

Select : “**Set up**”.

```
- SETUP (5) -
 1.Printer Setup
 2.Clock
 3.Antenna
 4.Basketing
>5.Other
```

Select “**Other**”

Press <OK>.

```
*** OTHER ***
>1.Language
 2.Password
 3.PCCom
```

Select “**Language**”

Press <OK>.

```
- LANGUAGE (5)-
 1.Nederlands
->2.English
 3.Francais
```

Select the language of your choice.

Press <OK>.

The EC switches to your selected language.

4.1.8. Make a PC communication.

Function: If a PC communication has to be made, the following submenu has to be installed.

```
- Little 1000 -
> Clocking
  Menu
Time : 10:36:23
```

This is the start-up menu.

```
- Little 1000 -
  Clocking
> Menu
Time : 10:36:51
```

By pressing the “↓” key on the keyboard of the EC the item “**Menu**” can be selected.

Press <OK>.

```
- MENU (5)-
1.Race
2.Use data
3.Options
4.Set up
>5.PC interface
```

In the next display 5 submenus appear. (The number between brackets indicates the number of submenus) We only see 3 submenus. By pressing the “↓” key, or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected. Select “**PC interface**”.

```
Key please!
```

Hold the antenna badge above the basketing antenna.

```
PC-comm. on hold
Press a key.
```

The EC is now ready to communicate with the PC. This procedure is necessary to exchange data between the PC and the EC. Press any key to stop.

5. Basketing.

The way of synchronising you choose when basketing also has to be used during the reading.

5.1. Basketing, synchronisation with the atomic clock.

Set the clocktype on 'Atomic clock'; see description 4.1.4. **Set the clock type..**

Install the BRICON CLUBSYSTEM as shown in item 2. **Parts and installation of the BRICON CLUBSYSTEM.**

For basketing, it is **not necessary** to have a PC communication. Next steps have to be followed.

```
- Little 1000 -
>Clocking
  Menu
Time    16:14:19
```

This is the start-up menu.

```
- Little 1000 -
  Clocking
>Menu
Time :   16:14:19
```

By pressing the "↓" key on the keyboard of the EC the item "**Menu**" can be selected.

Press <OK>.

```
- MENU (5) -
>1. Race
  2. Use data
  3. Options
4. Set up
5. PC-interface
```

In the next display 5 submenus appear. (The number between brackets indicates the number of submenus) We only see 3 submenus. By pressing the "↓" key, or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected. Select "**Race**".

Press <OK>.

```
- RACE (4)-
>1. Basketing
  2. Read
  3. Bets
4. Designated
5. Master clock
```

Select "**Basketing**".
Press <OK>.

```
Key please
```

Hold the antenna badge above the basketing antenna.

```
Choose race :
>01. Race 1
  02. Race 2
  03. Race 3
```

By using the arrows we can select the race we want.
Press <OK>.


```
Enter distance:
```

If speed calculation is set the EC will ask for race the distance (in meters).

```
Ra: Race 1
Hold pigeon in
the antenna
N:0      18:28:50
```

Hold the pigeon which has to be basketed above the basketing antenna. If that ring number is **not** mentioned on the pigeon list, an error message will appear. The electronic clock will ask to make an emergency entry! (See **7.4. Pigeon not listed! Emergency entry while basketing.**)

```
FR-00-1234578V
Time : 14:30:25
Ra: Race 1
Des. :1 <OK>
```

The display shows the ring number, time of basketing, the race and the designated pigeon.

Check the ring number and press <OK>.

```
Ra: Race 1
Hold pigeon in
the antenna
N:2      18:34:55
```

Repeat these steps as long as pigeons have to be basketed.

Press <C> if all pigeons are basketed.

If automatic printing (See **4.1.3. Set auto print..**) is activated a basketing list will be printed (See **5.4. The basketing list in detail**).

```
- RACE (4)-
>1.Basketing
  2.Read
  3.Bets
```

Following display appears.

Disconnect the EC.
The next fancier can basket.

5.2. Basketing, synchronise manually.

Set the clocktype on 'Manual'; see description **4.1.4. Set the clock type..**

Install the BRICON CLUBSYSTEM as in item **2.Parts and installation of the BRICON CLUBSYSTEM**. The mother cbck is not included in this set up. It is **not necessary** to have a PC connection for basketing. Next steps have to be followed.

```
- Little 1000 -
>Clocking
  Menu
Time      16:14:19
```

This is the start-up menu

```
- Little 1000 -
  Clocking
>Menu
Time :   16:14:19
```

By pressing the “↓” key on the keyboard of the EC “**Menu**” can be selected.

Press <OK>.

- MENU (5) -

>1. Race
2. Use data
3. Options

4. Set up
5. PC interface

In the next display 5 submenus appear. (The number between brackets indicates the number of submenus)
We only see 3 submenus. By pressing the “↓” key, or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected. Select **“Race”**.
Press <OK>.

- RACE (4)-

>1. Basketing
2. Read
3. Bets

4. Designate
5. Master clock

Select **“Basketing”**.
Press <OK>.

Key please !

Hold the antenna badge above the basketing antenna.

Choose race :

>01. Race 1
02. Race 2
03. Race 3

By using the arrows we can select the race we want.
Press <OK>.

Enter time
manually ?

<C> No <OK> Yes

Press <OK>, to install the time manually.

Enter date:

Date : 00/00/00
Time : 00:00:00

Enter the correct settings.
Values must be between 1 and 31 for the day, between 1 and 12 for the month, between 0 and 23 for the hour, between 0 and 59. for the minutes and seconds.
Use the 2 last digits of the year for the year setting (f.e. 01 for 2001).

```
Date : 11/07/00
Time  : 18:35:00
Press <OK> to
synchronise
```

Press <OK> to start the time.

```
Enter distance:
```

If speed calculation is set the EC will ask for race the distance (in meters).

```
Ra : Race 1
Hold pigeon in
the antenna
N:0      18:28:50
```

Hold the pigeon which has to be basketed above the basketing antenna. If that ring number is **not** mentioned on the pigeon list, an error message will appear. The electronic clock will ask to make an emergency entry! (See **7.4. Pigeon not listed! Emergency entry while basketing.**)

```
FR-00-1234578V
Time: 14:30:25
Ra: Race 1
Des. :1 <OK>
```

The display shows the ring number, time of basketing, the race and the designated pigeon.

Check the ring number and press <OK>.

```
Ra: Race 1
Hold pigeon in
the antenna
N:2      18:34:55
```

Repeat these steps as long as pigeons have to be basketed.

Press <C> if all pigeons are basketed.

If automatic printing (See **4.1.3. Set auto print..**) is activated, a basketing list will be printed (See **5.4. The basketing list in detail**).

```
- RACE (4)-
>1.Basketing
  2.Read
  3.Bets
```

Following display appears.

Disconnect the EC.
The next fancier can basket.


5.3. Basketing, synchronise with the master clock.

Set the clocktype on 'Master clock'; see description 4.1.4. Set the clock type..

A master clock has to be installed. This means that the timer of 1 EC (usually the EC of the first fancier who baskets) is used as a reference. Also the master clock functions during the race as an electronic clock, pigeons are basketed, clocked and read with it, just like any other electronic clock. It is not necessary always to use the same electronic clock as a master clock. Any electronic clock can function as a master clock.

Note: Per race only 1 electronic clock can function as a master clock.

Install the BRICON CLUBSYSTEM as shown in the figure 1 below.



1. Basketing antenna.
2. Printer.
3. PC.
4. BRICON Electronic clock (EC).
5. BRICON Electronic clock (EC) - Masterclock.

Figure 1

It is **not necessary** to have a PC communication. Next steps have to be followed.

```
- Little 1000 -
>Clocking
  Menu
Time: 16:14:19
```

This is the start-up menu.

```
- Little 1000 -
  Clocking
>Menu
Time : 16:14:19
```

By pressing the “↓” key on the keyboard of the EC the item “**Menu**” can be selected.

Press <OK>.

```
- MENU (5) -
>1. Race
  2. Use data
  3. Options
  4. Set up
  5. PC interface
```

In the next display 5 submenus appear. (The number between brackets indicates the number of submenus) We only see 3 submenus. By pressing the “↓” key, or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected. Select “**Race**”.

Press<OK>

```
- RACE (4)-
>1.Basketing
  2.Read
  3.Bets
  4.Designate
  5.Master clock
```

Select “**Basketing**”.

Press <OK>.

Key please !

Hold the antenna badge above the basketing antenna.

```
Choose race :
>01.Race 1
  02.Race 2
  03 Race 3
```

By using the arrows we can select the race we want.

Press <OK>.

```
Clock not
connected !!!
Try again ?
<C> No <OK> Yes
```

While basketing the pigeons with the master clock, the BRICON CLUBSYSTEM will report “clock not connected”.

Press <C>.

```
Install time
manually ?
<C> No <OK> Yes
```

The time of the master clock is entered manually.

Press <OK>.

```
Enter date:
Date : 00/00/00
Time : 00:00:00
```

Enter the correct settings.

Values must be between 1 and 31 for the day, between 1 and 12 for the month, between 0 and 23 for the hour, between 0 and 59. for the minutes and secondes.

Use the 2 last digits of the year for the year setting (f.e. 01 for 2001).

Date : 11/07/00
 Time : 18:35:00
 Press <OK> to
 synchronise

Press <OK> to start the time (synchronise).

Enter distance:

If speed calculation is set the EC will ask for race the distance (in meters).

Ra: Race 1
 Hold pigeon in
 the antenna
 N:0 18:28:50

Hold the pigeon which has to be basketed above the basketing antenna. If that ring number is **not** mentioned on the pigeon list, an error message will appear. The electronic clock will ask to make an emergency entry! (See **7.4. Pigeon not listed! Emergency entry while basketing.**)

FR-00-1234578V
 Time: 14:30:25
 Ra: Race 1
 Des.: 1 <OK>

The display shows the ring number, time of basketing, the race and the designated pigeon. Check the ring number and press <OK>.

Ra: Race 1
 Hold pigeon in
 the antenna
 N:2 18:34:55

Repeat these steps as long as pigeons have to be basketed.

Press <C> if all pigeons are basketed.

- RACE (4)-
 1. Basketing
 2. Read
 3. Bets

If automatic printing (**See 4.1.3. Set auto print..**) is activated, a basketing list will be printed (**See 5.4. The basketing list in detail**).

The master clock will stay connected at one end of the split cable.

4. Designate
 >5. Master clock.
 6. Release flight

Select "**Master clock**".
 Press <OK>.

Date: 01/06/99
 Time :
 20:19:42
 <C> Stop

The master clock is now installed and pigeons are being basketed, all the following electronic clocks are synchronised with the master clock. Press <C> when all fanciers have basketed.

Important:

1. After the race the master clock should be read first.
2. The reading of the race should be done by the same master clock as used for the basketing !

Set the clocktype on 'Master clock'; see description 4.1.4. Set the clock type..

Connect the electronic clock of the next fancier to the other end of the split cable (See Figure1 above).

```
- Little 1000 -
>Clocking
  Menu
Time : 16:14:19
```

This is the start-up menu.

```
- Little 1000 -
  Clocking
>Menu
Time : 16:14:19
```

By pressing the “↓” key on the keyboard of the EC the item “**Menu**” can be selected. Press <OK>.

```
- MENU (5) -
>1.Race
  2.Use data
  3.Options
4.Set up
5.PC interface
```

In the next display 5 submenus appear. (The number between brackets indicates the number of submenus) We only see 3 submenus. By pressing the “↓” key, or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected. Select “**Race**”. Press <OK>.

```
- RACE (4)-
>1.Basketing
  2.Read
  3.Bets
4.Designated
5.Master clock
```

Select “**Basketing**”. Press <OK>.

```
Key please !
```

Hold the antenna badge above the basketing antenna.

```
Choose race :
>01.Race 1
  02.Race 2
  03 Race 3
```

By using the arrows we can select the race we want. Press <OK>.

Enter distance:

If speed calculation is set the EC will ask for race the distance (in meters).

Ra: Race 1
Hold pigeon in
the antenna
N:0 18:28:50

Hold the pigeon which has to be basketed above the basketing antenna. If that ring number is **not** mentioned on the pigeon list, an error message will appear. The electronic clock will ask to make an

FR-00-1234578V
Time : 14:30:25
R1: Race 1
Des. :1 <OK>

emergency entry! (See **7.4. Pigeon not listed!**

Emergency entry while basketing.)

The display shows the ring number, time of basketing, the race and the designated pigeon

Ra: Race 1
Hold pigeon in
the antenna
N:2 18:34:55

Check the ring number and press <OK>.

Repeat these steps as long as pigeons have to be basketed.

Press <C> if all pigeons are basketed.

If automatic printing (**See 4.1.3. Set auto print..**) is activated, a basketing list will be printed (**See 5.4. The basketing list in detail**).

- RACE (4) -
>1. Basketing
2. Read
3. Bets

Next display appears.

Disconnect the electronic clock from the split cable. The next fancier can basket.

5.4. The basketing list in detail.

Basketing list

Race nr. : _____ Date : XX/XX/XX(1) RACE: XXXXXX (9)

Member : XXXX XXXX (2)

Name : XXXX XX (3)

X- Coordinate : XXXXXX (4)

Y- Coordinate : XXXXXX (4)

Print date : XX/XX/XX XX:XX:XX (5)

Strike IN: XX/XX/XX XX:XX:XX (6)

Basketed : X (7)

(8) Club :

Distance : 120451 (8.1)

DES	ID number	Electr. Controle	Day	Bask. Time Time	REMARKS
1	NL-00-3141399	7A58AF47	5/06/00	14:03:54	
2	NL-00-3141399	7A12E1A2	5/06/00	14:04:42	
3	NL-00-3141399	7AE125A4	5/06/00	14:05:15	

(10)

(11)

(12)

(13)

(14)

(1) date of the print out.

(2) member number.

(3) name of the fancier

(4) coordinates of the loft of the fancier.

(5) date and time of print out

(6) date and time of read

(7) number of pigeons basketed.

(8) club where pigeons are basketed.

(8.1) race distance.

(9) race

(10) designation of the pigeon.

(11) official ring of the federation.

(12) code of the chip ring (electronic ring).

(13) day and time of basketing.

(14) zone for remarks.

(15) signature(s).

(16) software version of the electronic clock (EC).

(17) address of the fancier.

(18) serial number of the electronic clock (EC).

Signature

(15)

.....

- Little 1000 -

Vers: TW-08

(16)

Serienr: BB129B

Address : XXX XX

(18)

XXXX XXXXXX (17)

6. Reading

6.1. Reading, synchronise with the atomic clock.

Install the BRICON CLUBSYSTEM as shown in item **2.Parts and installation of the BRICON CLUBSYSTEM.**

For reading, it is **not necessary** to have a PC communication. Next steps have to be followed.

```
- Little 1000 -  
>Clocking  
Menu  
Time 16:14:19
```

This is the start-up menu.

```
- BRICON 1000 -  
Clocking  
->Menu  
Time : 16:14:19
```

By pressing the “↓” key on the keyboard of the EC the item “**Menu**” can be selected.

Press <OK>.

In the next display 5 submenus appear. (The number between brackets indicates the number of submenus)

```
- MENU (5) -  
>1. Race  
2. Use data  
3. Options  
4. Set up  
5. PC interface
```

We only see 3 submenus. By pressing the “↓” key, or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected. Select “**Race**”.

Press<OK>.

```
- RACE (4)-  
1.Basketing  
>2.Read  
3.Bets  
4.Designate  
5.Master clock
```

Select “**Read**”.

Press <OK>.

```
Key please !
```

Hold the antenna badge above the basketing antenna.

```
Choose race :  
>01.Race 1  
03 Race 3
```

By using the arrows we can select the race we want. Press <OK>.

Enter the releasetime settings.

Values must be between 1 and 31 for the day, between 1 and 12 for the month, between 0 and 23 for the hour, between 0 and 59. for the minutes and secondes.

```
Releasetime:  
Date : 05/05/00  
Time : 09:05:00
```

Use the 2 last digits of the year for the year setting (f.e. 01 for 2001).

```
How many copies?
```

Fill out the number of copies to print.

A **clocking list** will be printed. (See 6.4. The clocking list in detail).

```
- RACE (4)-
>1.Basketing
  2.Read
  3.Bets
```

Next display appears.

Disconnect the EC.

The reading of the next electronic clock can be done.

6.2. Reading, synchronise manually

Install the BRICON CLUBSYSTEM as shown in item **2.Parts and installation of the BRICON CLUBSYSTEM**.

For reading, it is **not necessary** to have a PC communication. Next steps have to be followed.

```
- BRICON 1000 -
>Clocking
  Menu
Time      16:14:19
```

This is the start-up menu.

```
- BRICON 1000 -
  Clocking
>Menu
Time :   16:14:19
```

By pressing the “↓” key on the keyboard of the EC the item “**Menu**” can be selected.

Press <OK>.

```
- MENU (5) -
>1. Race
  2. Use data
  3. Options
  4. Set up
  5. PC interface
```

In the next display 5 submenus appear. (The number between brackets indicates the number of submenus) We only see 3 submenus. By pressing the “↓” key, or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected. Select “**Race**”.

Press<OK>

```
- RACE (4)-
  1.Basketing
>2.Read
  3.Bets
  4.Designate
  5.Master clock
```

Select “**Read**”.

Press <OK>.

Key please !

Hold the antenna badge above the basketing antenna.

Choose race :
>01.Race 1
03 Race 3

By using the arrows we can select the race we want.
Press <OK>.

Enter time
manually ?

Press <OK>, to install the time manually.

<C> No <OK> Yes

Enter the correct settings.

Enter date:
Date : 15/10/00
Time : 18:56:00

Values must be between 1 and 31 for the day,
between 1 and 12 for the month, between 0 and 23 for
the hour, between 0 and 59. for the minutes and
seconds.

Use the 2 last digits of the year for the year setting
(f.e. 01 for 2001).

Date : 15/08/99
Time : 18:56:00
Press <OK> to
synchronise

Press <OK> when time is achieved. From that
moment time is running.

Releasetime:
Date : 05/05/00
Time : 09:05:00

Enter the releasetime settings.

Values must be between 1 and 31 for the day,
between 1 and 12 for the month, between 0 and 23 for
the hour, between 0 and 59. for the minutes and
seconds.

Use the 2 last digits of the year for the year setting
(f.e. 01 for 2001).

How many copies?

Fill out the number of copies.

Free racing
data ?

Release racing data by pressing <OK>.

<C> No <OK> Yes

A clocking list will be printed. (See 6.4. The clocking list in detail).

- RACE (4)-
>1.Basketing
2.Read
3.Bets

Following display appears.
Disconnect the EC.
The next fancier can basket.

6.3. Reading, synchronise with the Master clock.

Install the BRICON CLUBSYSTEM as shown in the figure below.




Figure 1

The reading of the Master clock has to be done first (electronic clock with the time reference)

It is **not necessary** to have a PC communication. Next steps have to be followed.

```
- Little 1000 -
>Clocking
  Menu
Time: 16:14:19
```

This is the start-up menu.

```
- Little 1000 -
  Clocking
>Menu
Time: 16:14:19
```

By pressing the “↓” key on the keyboard of the EC the item “**Menu**” can be selected.

```
- MENU (5) -
>1.Race
  2.Use data
  3.Options
```

Select “**Race**”.

Press <OK>.

```
4.Set up
5.PC interface
```

```
- RACE (4)-
  1.Basketing
>2.Read
  3.Bets
```

Select “**Read**”.

Press <OK>.

```
4.Designated
5.Master clock
```

```
Key please!
```

Hold the antenna badge above the basketing antenna.

```
Choose race :
>01.Race 1
  03 Race 3
```

By using the arrows we can select the race we want.
Press <OK>.

```
Clock not
connected !!!
Try again ?
<C> No <OK> Yes
```

While reading the Master clock (electronic clock used as a time reference) the BRICON CLUBSYSTEM will register “clock not connected.”
Press <C>.

```
Enter time
manually ?

<C> No <OK> Yes
```

The time of the Master clock is installed manually.
Press <OK>.

Enter date:
Date : 15/10/00
Time : 18:56:00

Enter the correct settings.
Values must be between 1 and 31 for the day, between 1 and 12 for the month, between 0 and 23 for the hour, between 0 and 59. for the minutes and seconds.

Date : 15/08/99
Time : 18:56:00
Press <OK> to
synchronise

Use the 2 last digits of the year for the year setting (f.e. 01 for 2001).

Press <OK> when time is achieved. From that moment time is running.

Releasetime:
Date : 05/05/00
Time : 09:05:00

Enter the releasetime settings.

Values must be between 1 and 31 for the day, between 1 and 12 for the month, between 0 and 23 for the hour, between 0 and 59. for the minutes and seconds.

Use the 2 last digits of the year for the year setting (f.e. 01 for 2001).

How many copies?

Fill out the number of copies to print.

Free racing
data?

Release racing data by pressing <OK>.

<C> No <OK> Yes

A **clocking list** will be printed. (See 6.4. The clocking list in detail).

- RACE (4)-
1. Basketballing
2. Read
3. Bets
4. Designated
>5. Master clock.

The master clock will stay connected at one end of the split cable.

Select "**Master clock**".

Press <OK>.

Date: 01/06/99
Time :
20:19:42
<C> Stop

The electronic clock will function as a master clock and its timer will be a reference for all the other electronic clocks.

Important: Beware to use the same Master clock for both basketballing and reading.

Connect the electronic clock of the next fancier to the end of the split cable (See figure 1).

```
- RACE (4)-
 1.Basketing
>2.Read
 3.Bets
```

Select "**Read**".
Press <OK>.

```
4.Designate
5.Master clock
```

```
Key please !
```

Hold the antenna badge above the basketing antenna.

```
Choose race :
>01.Race 1
```

By using the arrows we can select the race we want.
Press <OK>.

```
Releasetime:
Date : 05/05/00
Time  : 09:05:00
```

Enter the releasetime settings.
Values must be between 1 and 31 for the day,
between 1 and 12 for the month, between 0 and 23 for
the hour, between 0 and 59. for the minutes and
seconds.
Use the 2 last digits of the year for the year setting
(f.e. 01 for 2001).

```
How many copies?
```

Fill out the number of copies to print.

```
Free racing
data?

<C> No <OK> Yes
```

Release racing data by pressing <OK>.

A **clocking list** will be printed. (See 6.4. The clocking list in detail).

```
- RACE (4)-
>1.Basketing
 2.Read
 3.Bets
```

Next display appears.

Disconnect the EC.
The reading of the next electronic clock can be done.

Note: If necessary the last series of clockings of the EC can be printed. (See 7.10. **Printing the log book. – Overview of the last series of clockings.**)

6.4. The clocking list in detail.

CLOCKING LIST

Race nr: _____ Date : XX/XX/XX **(1)** Race : Race 1 **(9)**
 Member : XXXX XXXX **(2)** Name : XXX **(3)**
 X-Coordinate : XXXXXX **(4)** Y- Coordinate : XXXXXX **(4)**
 Print date : XX/XX/XX XX:XX:XX **(5)** Strike OUT :10/08/99 18:36:52**(10)**
 Strike IN : XX/XX/XX XX:XX:XX **(6)** Clock timer:10/08/99 18:36:54**(11)**
 Difference:+002**(12)**
 Basketed : X **(7)** Club : **(8)**
 Distance: 120451, **(8.1)** Releasedate : 10/08/00 11:00 **(8.2)**

POS	number	Electr. Controle	Clocking time		DES	EV
			Day	Time		
4	NL-00-0001234514	7A5C9744	10/08/00	12:22:39	4	OK 1462,1 M/min
2	NL-00-0001234573	7A3B62AD	10/08/00	12:24:16	2	OK 1429,4 M/min
1	NL-00-0001234568	7A599E44	10/08/00	12:27:04	1	OK 1383,4 M/min
3	NL-00-0001234585	7A488E41	10/08/00	12:29:53	3	OK 1340,1 M/min

-(13.1)----- (13.2)----- (13.3)----- (13.4)----- (13.5)----- (13.6)----- (13.7)-----

- (1)** date of the print out.
- (2)** member number.
- (3)** name of the fancier
- (4)** coordinates of the loft of the fancier.
- (5)** date and time of print out
- (6)** date and time of basketing
- (7)** number of pigeons basketed.
- (8)** club where pigeons are basketed.
- (8.1)** race distance.
- (8.2)** time when the pigeons were released.
- (9)** race
- (10)** date and time of read.
- (11)** timer by read
- (12)** difference in time ('+' clock has gained, '-' clock is behind)
- (13.1)** designation of the pigeon.
- (13.2)** official ring of the federation.
- (13.3)** code of the chip ring (electronic ring).
- (13.4)** day of clocking.
- (13.5)** time of clocking.
- (13.6)** designation of the pigeon.
- (13.7)** evaluation and speed in meters/hour.
- (14)** signature(s).
- (15)** software version of the electronic clock (EC).
- (16)** address of the fancier.
- (17)** serial number of the electronic clock (EC).

Signature
(14)

.....

- Little 1000 -

Versie : TW-08 **(15)**
Address : XXXXX

Serialn: BB129B **(16)**

XXXXX **(17)**
Page 1

7. Trouble shooting.

7.1. Power fails when basketing/adding a pigeon to a race.

All the pigeons which were already basketed, still remain in the EC of the fancier.

Restart and follow the next steps:

When power is restored, following display appears.

```
- RACE (4)-  
>1.Basketing  
  2.Read  
  3.Bets
```

Press <OK>.

```
4.Designated  
5.Master clock
```

```
Key please !
```

Hold the badge above the basketing antenna.

```
Choose race :  
>01.Race 1  
  02.Race 2  
  03 Race 3
```

By using the arrows we can select the race we want.
Press <OK>.

```
Race already  
basketed!  
Add pigeons ?  
<C> No  <OK> Yes
```

Press <OK> to add pigeons.

The procedure to basket can be continued.

7.2. Pigeon already basketed.

This means that the ring number of that pigeon is still present in the EC. Either old race data or old training data are still stored in the EC.

```
Pigeon already  
basketed !!!  
Cancel pigeon ?  
<C> No  <OK> Yes
```

Press <C>.

```
Key please !
```

Hold the badge above the basketing antenna.

Pigeon canceled

Press <OK>

Disconnect the EC. Supply power directly to the EC of the fancier and delete all data. (See **7.3. Removing data from the EC.**). If there is still unreleased data in the EC, the reading of the EC has to be done first. (See **6. Reading**).

Afterwards you can basket the pigeon for that flight (See **7.1. Power fails during basketing / adding a pigeon to a flight.**)

7.3. Removing data from the EC.

```
- Little 500 -
> Clocking
  Menu
Time : 15:45:56
```

This is the start-up menu.

```
- Little 500 -
  Clocking
> Menu
Time : 15:46:14
```

Select "**Menu**" with the arrows and press <OK>.

```
- MENU (5) -
 1.Race
>2.Use data
 3.Options
 4.Set up
 5.PC interface
```

Select "**Use data**" with the arrows or press 2.

Press <OK>.

```
- DATA (6) -
 1.Check clock.
>2.Delete
 3.Print
```

Select Delete with the arrows or press 2.

```
4.Pigeon list
 5.Clubs
 6.Race list
```

```
Delete all
released data?
```

Press <OK> to delete data.

```
<C> No  <OK> Yes
```

```
Delete data
Password :
```

Enter password. Standard "0000" (4 x zero).

Delete
designated

<C> No <OK> Ja

Press <OK> to delete the designated pigeons.

Erase clocking
history?

<C> No <OK> Ja

Press <OK> to delete the clocking history.

Deleting is completed.

7.4. Pigeon not listed! Emergency entry while basketing.

If the pigeon is not on the pigeon list, an emergency entry can be made.

When holding an unknown ring above the basketing antenna, following steps should be done:

Ring not listed
EMERGENCY ENTRY ?

<C> No <OK> Yes

Press <OK>.

Enter country
<OK> FR <1> BE
<2> PT <3> DV
<4> NL <0> Other

Fill out the corresponding country.
<OK> for France, <1> for Belgium, ...

Enter year
<OK> Ready
<Arrows> Select
FR-00

Enter the year. By means of the vertical arrows the year can be changed.

Ring ID number?
<OK> Ready
<Arrows> Select
FR-99-0000000

Enter the ring number (7 digits). By means of the horizontal arrows the digits can be changed.

Sex?
Hen Cock
 <C> <OK>
FR-99-1234567

Enter the sex, press <C> for hen, press <OK> for cock.

Are data below
correct ?
<C>No <OK> yes
FR-99-1234567

Confirm if correct.

Designate?

<C> No <OK> Yes

Press <OK> if the designation has to be entered.

Nr:FR-99-1234567
0=delete
Enter position:

Enter the position of the pigeon.

FR-99-1234567
Time : 15:49:45
Rl.:Race 1
Des. :5 <OK>

Press <OK> if data is correct.

The next pigeon can be basketed.

7.5. Wrong ring number while basketing.

This can happen if the fancier has changed the rings without knowledge of the club's responsible person. Follow the next steps:

Race :Race 1
Hold pigeon in
antenna
N:4 19:01:25

Hold the pigeon with the wrong ring number **within 5 minutes** once more above the basketing antenna.

Pigeon is already
basketed!
Cancel pigeon ?
<C> No <OK> Yes

Press <OK>.

Key please !

Hold the basketing badge above the antenna.

Pigeon cancelled

Press <OK>

The pigeon is cancelled and erased from the race.

Press <OK>.

Ring the pigeon with a new ring and proceed the basketing. The new ring requires an emergency entry (See **7.4. Pigeon not listed! Emergency entry while basketing.**) Execute this emergency entry and basketing of the remaining pigeons can proceed.

7.6. What is left in the fancier's EC?

When printing an overview, we get a general view of all the data in the EC. How to proceed ?

```
- Little 500 -
>Clocking
  Menu
Time : 16:14:16
```

Supply power to the EC.
This is the start-up menu.

```
- Little 500 -
  Clocking
>Menu
Time : 16:14:33
```

By pressing the “↓” key on the keyboard of the EC the item “**Menu**” can be selected.

Press <OK>.

```
- MENU (5)-
 1. Race
>2. Use data
 3. Options
4. Set up
5. PC interface
```

In the next display 5 submenus appear. (The number between brackets indicates the number of submenus) We only see 3 submenus. By pressing the “↓” key, or simply through pressing the number of the submenu on the keyboard of the EC, the submenu will be selected. Select “**Use data**”. Press <OK>.

```
- DATA (6)-
 1. Clockings
 2. Delete
>3. Print
```

Select “**Print**”.

Press <OK>.

```
- PRINT (8)-
>1.Overview
 2.T.Clock list
 3.R.Clock list
```

```
4.Bets
5.Pigeon list
6.Races
7.Designate
8.Basketinglist
9.Clocking list
```

In the next display 8 submenus appear from which you can make a selection. Select “**Overview**”. A general overview of all data in the EC will be printed.

7.7. The ring is not being read.

The ring is damaged. Ring the pigeon with a new ring and make an emergency entry (See 7.4. **Pigeon not listed! Emergency entry while basketing.**)

7.8. New print of the basketing list.

Please follow next steps:

<pre>- RACE (4)- >1. Basketing 2. Read 3. Bets</pre>	<p>Install the BRICON CLUBSYSTEM as shown in item 2.Parts and installation of the BRICON CLUB-SYSTEM. Connect power supply. Select "<i>Basketing</i>"</p>
<pre>4. Designated 5. Master clock</pre>	<p>Press <OK>.</p>
<pre>Key please !</pre>	<p>Hold the antenna badge above the basketing antenna.</p>
<pre>Choose race : >01:Race 1 02:Race 2 03:Race 3</pre>	<p>Select the race from which a new basketing list has to be printed.</p>
<pre>Race already basketed! Add pigeons <C> No <OK> Yes</pre>	<p>Press <OK>.</p>
<pre>Ra: Race 1 Hold pigeon in antenna N:2 19:26:16</pre>	<p>Press <C>. A new basketing list is printed.</p>

Repeat the same steps to print the clocking list. In the main menu you should choose Read instead of Basketing. The clocking list can be printed all over again as long as it has not been removed from the EC.

7.9. Accidentally pressed <C> before the last pigeon was fully basketed.

Next steps have to be followed:

```
- RACE (4)-
>1.Basketing
  2.Read
  3.Bets
4.Designated
5.Master clock
```

Disconnect the power for a while.
Supply power again.

Press <OK>.

```
Key please !
```

Hold the antenna badge above the basketing antenna.

```
Choose race :
>01.Race 1
  02.Race 2
  03 Race 3
```

By using the arrows we can select the race we want.
Press <OK>.

```
Race already
basketed!
Add pigeons ?
<C> No  <OK> Yes
```

Press <OK> to add pigeons.

7.10. Print logbook. –Overview of the last series of clockings.

Install the BRICON CLUBSYSTEM as shown in item **2.Parts and installation of the BRICON CLUBSYSTEM.**

```
- RACE (4)-
>1.Basketing
  2.Read
  3.Bets
```

Press '985' on the keyboard.

```
How many
clockings?
```

Enter the number of clockings that have to be printed.

Press <OK>.

```
How many copies?
```

Fill out the number of copies to print.

Press <OK>.

A list of the number of **clockings** will be printed. (See **7.10.1. Logbook in detail**).

7.10.1. Logboek in detail.

Logboek

Date : XX/XX/XX (1)

Member : XXXX XXXX (2)

Name : XXXX XX (3)

X- Coordinate : XXXXXX (4)

Y- Coordinate : XXXXXX (4)

Print date : XX/XX/XX XX:XX:XX (5)

Ring :	Time	Eval		Ring	Time	Eval	
7A58BA7	05/06	15:52:54	Ok	7A131AC	05/06	15:52:36	Ok
7A58AF4	05/06	15:52:28	Ok	7A3B52A	05/06	15:52:09	Ok
7A3B52A	04/06	16:13:21	Ok	7A131AC	04/06	16:13:01	Ok
7A131AC	04/06	16:12:57	Ok	7A58BA7	04/06	16:10:59	Ok
7A131AC	03/06	09:41:25	Ok	7A131AC	03/06	09:40:12	Ok
7A3B52A	03/06	09:38:32	Ok	7A58BA7	03/06	09:38:30	Ok
(6)	(7)	(8)		(6)	(7)	(8)	

(1) date of the print out.

(2) member number.

(3) name of the fancier

(4) coordinates of the loft of the fancier.

(5) date and time of print out

(6) official ring of the federation.

(7) date of clocking.

(8) time of clocking.

(9) evaluation

(10) signature(s).

(11) software version of the electronic clock (EC).

(12) address of the fancier.

(13) serial number of the electronic clock (EC).

Signature

(10)

- Little 1000 -

Vers: TW-08

(11)

Serienr:

BB129B

Address : XXX XX

XXXX XXXXXX (12)

(13)

Page 1

7.11. Printing basketing list from the EC.

Function: In this item all kind of print-outs can be made with data from the EC.

```
- Little 1000 -  
> Clocking  
  Menu  
Time : 16:14:16
```

This display shows the startup menu.

```
- Little 1000 -  
  Clocking  
> Menu  
Time : 16:14:16
```

Press the “↓” arrow on the EC display till “**Menu**” is selected.
Press <OK>.

```
- MENU (5) -  
 1.Race  
>2.Use data  
 3.Options  
4.Set up  
5.PC Interface
```

On the new display 5 submenu’s are showed. (The figure next to Menu gives the amount of submenus.) We only see 3 submenu’s. Pressing “↓”, or by dialing the figure before the submenu on the EC (BA), a submenu can be selected.
Select : “**Use data**”.

```
- USE DATA (6)-  
 1.Overview  
 2.Delete  
>3.Print  
 4.Pigeonlist  
 5.Clubs  
 6.Calender
```

Press<OK>.

Select “**Print.**”.

Press<OK>.

8 submenu’s will appear on the display.

```
- PRINT (8)-  
 1.Overview  
 2.T.clock list  
 3.R.clock list  
4.Bets  
 5.Pigeon list  
 6.Races  
 7.Designation  
>8.Basketinglist  
 9 Clocking list
```

Select “**Basketinglist**”

Press <OK>.

```
Choose race :  
>01:race 1  
 03:race 3
```

Choose the race.

Press<OK>.

How many copies?

Give the number of copies.

The basketing list of the selected race is printing.

The BRICON CLUBSYSTEM is homologated by your federation. Abuse of this device or lending it to a third party, who is not part of the management or who is not working personnel, is an offence.

BRICON nv

Hoge Heerweg, 49 9100 Sint-Niklaas Belgium
Tel: +32 (0)3/ 777 39 74 Fax: +32 (0)3/ 778 07 35
website: www.bricon.be / e-mail: bricon@bricon.be

Countries where BRICON is homologated :

*Australia
The Balkans
Belgium
Canada
France
Germany
Gulf States
Hungary*

*The Netherlands
New Zealand
Portugal
Spain
Taiwan
United States
South Africa*